
# **Rakks**


# **EHV Vanity Support Bracket**

#### EH-LV-80



 $18" \times 21 \frac{1}{2}"$  counter depth up to 25" weight capacity 450 lbs

#### EH-1818-LV



18" × 21 ½" counter depth up to 25" weight capacity 450 lbs

Weight capacity is based on evenly distributed static loads

#### Parts included:



Heavy-duty aluminum Rakks ADA-compliant Vanity Support Brackets
Standard  $18 \times 21 \frac{1}{2}$ ", or custom size

Additionally, you will need:



 $\frac{1}{4}$ " ×  $2\frac{1}{2}$ " screws for mounting to wall



Vanity skirt



Construction adhesive or screws for countertop surface mounting according to manufacturer's recommendation

Measuring tape Pencil or painter's tape Level Stud finder Drill driver + 5/32" bit

## Acceptable mounting applications:

Blocking Studs Double studs Metal studs

Four (4) secured screws per bracket for up to 48" bracket spacing.

For other mounting surfaces, contact your Rakks representative.

# **Rakks**

# **EHV Vanity Support Bracket**

# 1

# Mark out the location of your vanity support brackets.


Determine the height from the floor to the bottom of your **countertop** surface.

Use a laser level, chalk line or tape measure and pencil to mark a level plane on the wall surface.

Slide the stud finder along this line and mark the exact center of each **stud** where a vanity bracket will be installed.

Hold the **bracket** against the wall at the stud location, ensuring that the center of the bracket is at the center of the stud.

Use a level to be sure the bracket is vertical, then mark the mounting holes.




# 2

#### Secure the brackets.

Place the bracket aside. Use a 5/32" drill bit to drill pilot holes at a slight inward angle (**toeing**). This will ensure that all screws are fully engaged.

**Note:** The live load capacity per bracket is reduced if you are installing into metal studs or have only 2 secured screws per bracket. Contact your Rakks representative for more information.



### 3

### Install the vanity.

Refer to the manufacturers' instructions for installing the basin and counter. The brackets have 4 holes for securing the **skirt** from behind.